Assembly option 1 (arm up)

③.₁

③.₂

⑥

⑤.₂

⑤.₁

②

④.₁

④.₂

①

Assembly option 2 (arm down)

⑤.₂

⑥

⑤.₁

ATTENTION!
Installation and changing arm direction should be carried out by electrican.
Power should be cut off before cleanliness or bulds changing

or

Wall-mounted

Instruction

LAMP4YOU
BY MAYTONI